

VISKON-AIRE CORP

SPRAY BOOTH MAINTENANCE

- *Sponge clean walls once a day.
- *Check fans and motors monthly.
- *Wash floors daily.
- *Run booth 30 minutes after filter change.

SUPPLY AIR - INTAKE FILTERS

Series 45, Series 55, 990 PBE, VA-600/N, VA-550/N, T-700/G

- *Change crossdraft filters every 30 to 40 paint jobs.
- *Install Series 55 filters with green tackified side toward object being painted in crossdraft booths.
- *Change pre-filters quarterly.
- *Change ceiling filters every 800 to 1200 hours of use.
- *Filter changeout times vary with shop conditions, paint being applied, type of spray booth and condition of pre-filters.
- *Do not clean filters with high pressure air.

EXITING AIR - PAINT ARRESTORS SG-15, 107X, XHD, PS MEDIA

- *Arrestors too thin let paint pass into the exhaust duct.
- *Arrestors too dense will cause fogging.
- *Paint arrestors are oversized to provide a tight and efficient seal--use grids to support media.
- *Change arrestors every 15 to 25 paint jobs.
- *Filter change out times vary with object being painted, velocity, distance from gun to arrestor bank and type of spray booth.

Crossdraft Booth Part Number	Downdraft Booth Part Number
Intake Filters _____	Prefilters _____
	Ceiling Filters _____
Exhaust Filters _____	Exhaust Filters _____

800-336-3752